



FLOW & SERVE



TEEKANNE MIT SIEB TEAPOT WITH STRAINER BRONZE 0.30L

0007 21 4304 91 000000
= 12cm x 9cm / 4.72" x 3.54"
☕ 0.30l / 10.14oz
📖 700 g
📏 8cm / 3.15"
📦 1
💰 18,50 €



TEEKANNE MIT SIEB TEAPOT WITH STRAINER BLAU/BLUE 0.50L

0007 21 4306 91 000000
= 15cm x 12cm / 5.91" x 4.72"
☕ 0.50l / 16.91oz
📖 1100 g
📏 11cm / 4.33"
📦 1
💰 22,50 €



TEEKANNE MIT SIEB TEAPOT WITH STRAINER SALBEI/SAGE 0.40L

0007 21 4305 91 000000
= 15cm x 14cm / 5.91" x 5.51"
☕ 0.40l / 13.53oz
📖 1000 g
📏 8cm / 3.15"
📦 1
💰 20,50 €



TEEKANNE MIT SIEB TEAPOT WITH STRAINER BRAUN/BROWN 0.45L

0007 21 4307 91 000000
= 15cm x 13cm / 5.91" x 5.12"
☕ 0.45l / 15.22oz
📖 1100 g
📏 8cm / 3.15"
📦 1
💰 21,50 €



TEEKANNE MIT SIEB TEAPOT WITH STRAINER SCHWARZ/BLACK 0.50L

0007 21 4303 91 000000
= 15cm x 13cm / 5.91" x 5.12"
☕ 0.50l / 16.91oz
📖 950 g
📏 9cm / 3.54"
📦 1
💰 22,50 €



TEEKANNE MIT SIEB TEAPOT WITH STRAINER 1.10L

0007 21 4300 91 000000
= Ø16cm / Ø6.3"
☕ 1.10l / 37.20oz
📖 1453 g
📏 14cm / 5.51"
📦 1
💰 59,89 €



TEEKANNE MIT SIEB TEAPOT WITH STRAINER 1.10L

0007 21 4302 91 000000
= 22cm x 19.5cm / 8.66" x 7.68"
☕ 1.15l / 38.89oz
📖 2234 g
📏 8cm / 3.15"
📦 1
💰 65,11 €



TEEKANNE TEAPOT GROSS/LARGE

0007 51 4300 91 000000
= 17cm x 10cm / 6.69" x 3.94"
☕ 0.40l / 13.53oz
📖 140 g
📏 10cm / 3.94"
📦 1
💰 9,90 €





TEEKANNE
TEAPOT
KLEIN/SMALL

0007 51 4301 91 000000
 10.5cm x 6cm / 4.13" x 2.36"
 0.08l / 2.71oz
 40 g
 6.5cm / 2.56"
 1
 7,20 €



STÖVCHEN
WARMER
EICHE/OAK 14X14CM

0007 41 7900 91 000000
 14cm x 14cm / 5.51" x 5.51"
 -
 420 g
 5.5cm / 2.17"
 1
 29,94 €



STÖVCHEN
WARMER
NUSSBAUM/WALNUT 14X14CM

0007 42 7900 91 000000
 14cm x 14cm / 5.51" x 5.51"
 -
 360 g
 5.5cm / 2.17"
 1
 33,86 €



Preise gelten zzgl. Mehrwertsteuer. Unverbindliche Preisempfehlung – gültig ab 01.01.2025. Prices do not include the statutory VAT rate. Prices are non-binding – valid as from 01.01.2025.



SLOW COFFEE MAKER
SLOW COFFEE MAKER
SILBER/SILVER 0.60L

0007 51 9000 91 000000
 13.5cm x 12cm / 5.31" x 4.72"
 0.60l / 20.29oz
 380 g
 16cm / 6.3"
 1
 40,27 €



SLOW COFFEE MAKER
SLOW COFFEE MAKER
GOLD 0.60L

0007 51 9001 91 000000
 13.5cm x 12cm / 5.31" x 4.72"
 0.60l / 20.29oz
 380 g
 16cm / 6.3"
 1
 40,27 €



SLOW COFFEE MAKER
SLOW COFFEE MAKER
0.60L

0007 51 9002 91 000000
 Ø13.5cm / Ø5.31"
 0.60l / 20.29oz
 256 g
 16cm / 6.3"
 1
 20,87 €



GIESSER OHNE HENKEL
CREAMER WITHOUT HANDLE
0.20L

0007 01 4600 91 004262
 Ø8cm / Ø3.15"
 0.22l / 7.44oz
 175 g
 8.9cm / 3.5"
 6
 6,40 €



Preise gelten zzgl. Mehrwertsteuer. Unverbindliche Preisempfehlung – gültig ab 01.01.2025. Prices do not include the statutory VAT rate. Prices are non-binding – valid as from 01.01.2025.