



SEA



TELLER FLACH RUND COUP PLATE FLAT ROUND COUPE 15CM

0007 01 1215 91 000351

Ø15cm / Ø5.91"

210 g

2cm / 0.79"

6

6,25 €



TELLER FLACH RUND COUP PLATE FLAT ROUND COUPE 23CM

0007 01 1223 91 000351

Ø23cm / Ø9.06"

700 g

3cm / 1.18"

6

10,55 €



TELLER FLACH RUND COUP PLATE FLAT ROUND COUPE 28CM

0007 01 1228 91 000351

Ø28cm / Ø11.02"

-

1000 g

3cm / 1.18"

6

15,24 €



SCHÄLCHEN RUND SMALL DISH ROUND 9CM/0.10L

0007 01 3509 91 000351

Ø9cm / Ø3.54"

0.10l / 3.38oz

150 g

3.5cm / 1.38"

12

4,37 €



SCHÜSSEL RUND BOWL ROUND 15CM/0.35L

0007 01 3115 91 000351

Ø15cm / Ø5.91"

0.35l / 11.83oz

330 g

5.5cm / 2.17"

6

9,87 €



SCHÜSSEL RUND BOWL ROUND 24CM/1.50L

0007 01 3124 91 000351

Ø24cm / Ø9.45"

1.50l / 50.72oz

1035 g

7.5cm / 2.95"

6

22,62 €



SCHÜSSEL RUND BOWL ROUND 15CM/0.30L

0007 01 3114 91 000351

Ø15cm / Ø5.91"

0.30l / 10.14oz

410 g

4cm / 1.57"

6

8,05 €



SCHÜSSEL RUND BOWL ROUND 20CM/0.70L

0007 01 3120 91 000351

Ø20cm / Ø7.87"

0.70l / 23.67oz

760 g

5cm / 1.97"

6

13,76 €





SCHÜSSEL RUND

BOWL ROUND

24CM/0.90L

0007 01 3123 91 000351

Ø24cm / Ø9.45"

0.90l / 30.43oz

1140 g

5cm / 1.97"

6

18,13 €



PLATTE RECHTECKIG RELIEF

PLATTER RECTAN. EMBOSSED

22X10CM

0007 01 2122 91 000351

22cm x 10cm / 8.66" x 3.94"

-

360 g

3cm / 1.18"

6

13,83 €



PLATTE RECHTECKIG RELIEF

PLATTER RECTAN. EMBOSSED

27X12CM

0007 01 2127 91 000351

27cm x 12cm / 10.63" x 4.72"

-

490 g

3cm / 1.18"

2

18,19 €



PLATTE RECHTECKIG RELIEF

PLATTER RECTAN. EMBOSSED

36X16CM

0007 01 2136 91 000351

36cm x 16cm / 14.17" x 6.3"

-

950 g

3cm / 1.18"

2

26,86 €

